


# INSTALLATION MANUAL

- Thank you for purchasing this ecox product.
- Before using this machine, please read this manual and retain it for future reference.

EDFM  
inverter



<b>3</b>	SAFETY PRECAUTIONS
<b>4</b>	ACCESSORIES
<b>5</b>	INSTALLATION SUMMARY - INDOOR UNIT
<b>7</b>	UNIT PARTS
<b>8</b>	INDOOR UNIT INSTALLATION
<b>1</b>	Select installation location
<b>2</b>	Attach mounting plate to wall
<b>3</b>	Drill wall hole for connective piping
<b>4</b>	Prepare refrigerant piping
<b>5</b>	Connect drain hose
<b>6</b>	Connect signal cable
<b>7</b>	Wrap piping and cables
<b>8</b>	Connect indoor power wire
<b>9</b>	Mount indoor unit
<b>16</b>	OUTDOOR UNIT INSTALLATION
<b>1</b>	Select installation location
<b>2</b>	Install drain joint
<b>3</b>	Anchor outdoor unit
<b>4</b>	Connect signal and power cables
<b>21</b>	REFRIGERANT PIPING CONNECTION
<b>3</b>	Note on Pipe Length
<b>4</b>	Connection Instructions – Refrigerant Piping
<b>3</b>	Cut pipe
<b>4</b>	Remove burrs
<b>3</b>	Flare pipe ends
<b>4</b>	Connect pipes
<b>25</b>	AIR EVACUATION
<b>1</b>	Evacuation Instructions
<b>2</b>	Note on Adding Refrigerant
<b>27</b>	ELECTRICAL AND GAS LEAK CHECKS
<b>28</b>	TEST RUN
<b>30</b>	EUROPEAN DISPOSAL GUIDELINES

## SAFETY PRECAUTIONS

### Read Safety Precautions Before Installation

- Incorrect installation due to ignoring instructions can cause serious damage or injury.
- The seriousness of potential damage or injuries is classified as either a WARNING or CAUTION.



#### WARNING

Indicates that ignoring instructions may cause moderate injury to your person, or damage to your unit or other property.



#### CAUTION

This symbol indicates that ignoring instructions may cause moderate injury to your person, or damage to your unit or other property.



This symbol indicates that you must never perform the action indicated.



#### WARNING

- ⊘ Do not modify the length of the power supply cord or use an extension cord to power the unit.  
Do not share the electrical outlet with other appliances. Improper or insufficient power supply can cause fire or electrical shock.
- ⊘ When connecting refrigerant piping, do not let substances or gases other than the specified refrigerant enter the unit. The presence of other gases or substances will lower the unit's capacity, and can cause abnormally high pressure in the refrigeration cycle. This can cause explosion and injury.
- ⊘ Do not allow children to play with the air conditioner. Children must be supervised around the unit at all times.
- ❶ Installation must be performed by an authorized dealer or specialist. Defective installation can cause water leakage, electrical shock, or fire.
- ❷ Installation must be performed according to the installation instructions. Improper installation can cause water leakage, electrical shock, or fire. (In North America, installation must be performed in accordance with the requirement of NEC and CEC by authorized personnel only).
- ❸ Contact an authorized service technician for repair or maintenance of this unit.
- ❹ Only use the included accessories, parts, and specified parts for installation. Using non-standard parts can cause water leakage, electrical shock, fire, and can cause the unit to fail.
- ❺ Install the unit in a firm location that can support the unit's weight. If the chosen location cannot support the unit's weight, or the installation is not done properly, the unit may drop and cause serious injury and damage.

- ❻ For all electrical work, follow all local and national wiring standards, regulations, and the Installation Manual. You must use an independent circuit and single outlet to supply power. Do not connect other appliances to the same outlet. Insufficient electrical capacity or defects in electrical work can cause electrical shock or fire.
- ❼ For all electrical work, use the specified cables. Connect cables tightly, and clamp them securely to prevent external forces from damaging the terminal. Improper electrical connections can overheat and cause fire, and may also cause shock.
- ❽ All wiring must be properly arranged to ensure that the control board cover can close properly. If the control board cover is not closed properly, it can lead to corrosion and cause the connection points on the terminal to heat up, catch fire, or cause electrical shock.
- ❾ In certain functional environments, such as kitchens, server rooms, etc., the use of specially designed air-conditioning units is highly recommended.



#### CAUTIONS

- ⊘ For units that have an auxiliary electric heater, do not install the unit within 1 meter (3 feet) of any combustible materials.
- ⊘ Do not install the unit in a location that may be exposed to combustible gas leaks. If combustible gas accumulates around the unit, it may cause fire.
- ⊘ Do not operate your air conditioner in a wet room such as a bathroom or laundry room. Too much exposure to water can cause electrical components to short circuit.
- ❶ The product must be properly grounded at the time of installation, or electrical shock may occur.
- ❷ Install drainage piping according to the instructions in this manual. Improper drainage may cause water damage to your home and property.













#### NOTE


##### About fluorinated gasses

- ❶ This air-conditioning unit contains fluorinated gasses. For specific information on the type of gas and the amount, please refer to the relevant label on the unit itself.
- ❷ Installation, service, maintenance and repair of this unit must be performed by a certified technician.
- ❸ Product uninstallation and recycling must be performed by a certified technician.
- ❹ If the system has a leak-detection system installed, it must be checked for leaks at least every 12 months.
- ❺ When the unit is checked for leaks, proper record-keeping of all checks is strongly recommended.


## ACCESSORIES

The air conditioning system comes with the following accessories. Use all of the installation parts and accessories to install the air conditioner. Improper installation may result in water leakage, electrical shock and fire, or cause the equipment to fail.


NAME	SHAPE		QUANTITY	
Mounting plate			1	
Clip anchor			5	
Mounting plate fixing screw ST3.9 X 25			5	
Remote control			1	
Fixing screw for remote control holder ST2.9 x 10			2	Optional Parts
Remote control holder			1	
Dry battery AAA.LR03			2	
Air freshening filter			1	
Seal			1 (for cooling & heating models only)	
Drain joint				
Owner's manual			1	
Installation manual			1	
Remote control illustration			1	
Connecting pipe assembly	Liquid side	Φ 6.35( 1/4 in)	Parts you must purchase. Consult the dealer about the pipe size.	
		Φ 9.52( 3/8in)		
	Gas side	Φ 9.52( 3/8in)		
		Φ 12.7( 1/2in)		
		Φ 16( 5/8in)		




Select Installation Location  
(Page 8)




Determine Wall Hole Position  
(Page 9)




Attach Mounting Plate  
(Page 11)




Drill Wall Hole  
(Page 11)




Connect Piping  
(Page 23)




Connect Wiring  
(Page 14)



Prepare Drain Hose  
(Page 12)



Wrap Piping and Cable  
(Page 16)



Mount Indoor Unit  
(Page 16)




Fig. 2.1



## NOTE

*Illustrations in this manual are for explanatory purposes. The actual shape of your indoor unit may be slightly different. The actual shape shall prevail.*

## ELECTRICAL WORK

Electric safety regulations for the initial installation

- 1 If there is serious safety problem about the power supply, the technicians should refuse to install the air conditioner and explain to the client until the problem is solved.
- 2 Power voltage should be in the range of 90%~110% of rated voltage.
- 3 The surge protector and main power switch with a 1.5 times capacity of Max. Current of the unit should be installed in power circuit. Ensure the air conditioner is grounded well.
- 4 The appliance shall be installed in accordance with national wiring regulations. Do not operate your air conditioner in a wet room such as a bathroom or laundry room.
- 5 An all-pole disconnection device which has at least 3mm clearances in all poles, and have a leakage current that may exceed 10mA, the residual current device(RCD) having a rated residual operating current not exceeding 30mA, and disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.
- 6 For the unit adopts auxiliary electric heater, keep at least 1 meter away from the nearest combustible materials.
- 7 According to the attached Electrical Connection Diagram located on the panel of the indoor & outdoor unit to connect the wire.
- 8 All wiring must comply with local and national electrical codes and be installed by qualified and skilled electricians.
- 9 An individual branch circuit and single receptacle used only for this air conditioner must be available. See the following table for suggested wire sizes and fuse specifications:

Minimum cross-sectional area of conductors:

Appliance Amps	AWG Wire Size
10	18
13	16
18	14
25	12
30	10
40	8



### NOTE


- The wire size of power supply cord and interconnected wire and the current of the fuse or switch are determined by the maximum current indicated on the nameplate which located on the side panel of the unit. Please refer to the nameplate before selecting the wire size, fuse or switch.
- The controller of the air conditioner designed with a fuse protection function under abnormal conditions, the specifications of the fuse have printed on the circuit board, such as: 3.15A/250VAC, T5A/250VAC, etc.

## CONNECT THE CABLE TO THE INDOOR UNIT




### NOTE

- 1 Before performing any electrical work, turn off the main power to the system.
- 2 The inside and outside connecting cable can be connected without removing the front grille.
- 3 The indoor power cord type is H05VV-F or H05V2V2-F, the outdoor power cord and interconnected cord type is H07RN-F.
- 4 Lift the indoor unit panel up, remove the electrical box cover by loosening the screw.
- 5 Ensure the colour of wires of outdoor unit and the terminal Nos. are the same to the indoor s respectively.
- 6 Wrap those cables not connected with terminals with insulation tapes, so that they will not touch any electrical components. Secure the cable onto the control board with the cord clamp.







## INSTALLATION INSTRUCTIONS – INDOOR UNIT

### PRIOR TO INSTALLATION

Before installing the indoor unit, refer to the label on the product box to make sure that the model number of the indoor unit matches the model number of the outdoor unit.

### Step 1: Select installation location

Before installing the indoor unit, you must choose an appropriate location. The following are standards that will help you choose an appropriate location for the unit.

Proper installation locations meet the following standards:

- ☒ Good air circulation
- ☒ Convenient drainage
- ☒ Noise from the unit will not disturb other people
- ☒ Firm and solid—the location will not vibrate
- ☒ Strong enough to support the weight of the unit
- ☒ A location at least one meter from all other electrical devices (e.g., TV, radio, computer)

DO NOT install unit in the following locations:

- ☐ Near any source of heat, steam, or combustible gas
- ☐ Near flammable items such as curtains or clothing
- ☐ Near any obstacle that might block air circulation
- ☐ Near the doorway
- ☐ In a location subject to direct sunlight



### NOTE

#### About wall hole

*If there is no fixed refrigerant piping:*

*While choosing a location, be aware that you should leave ample room for a wall hole (see Drill wall hole for connective piping step) for the signal cable and refrigerant piping that connect the indoor and outdoor units.*

*The default position for all piping is the right side of the indoor unit (while facing the unit).*

*However, the unit can accommodate piping to both the left and right.*

Refer to the following diagram to ensure proper distance from walls and ceiling:




Fig. 3.1

### Step 2: Attach mounting plate to wall

The mounting plate is the device on which you will mount the indoor unit.

- 1 Remove the screw that attaches the mounting plate to the back of the indoor unit.
- 2 Place the mounting plate against the wall in a location that meets the standards in the Select Installation Location step. (See Mounting Plate Dimensions for detailed information on mounting plate sizes.)
- 3 Drill holes for mounting screws in places that:
  - have studs and can support the weight of the unit
  - correspond to screw holes in the mounting plate
- 4 Secure the mounting plate to the wall with the screws provided.
- 5 Make sure that mounting plate is flat against the wall.

### Step 3: Drill wall hole for connective piping

You must drill a hole in the wall for refrigerant piping, the drainage pipe, and the signal cable that will connect the indoor and outdoor units.

- 1 Determine the location of the wall hole based on the position of the mounting plate. Refer to Mounting Plate Dimensions on the next page to help you determine the optimal position. The wall hole should have a 65mm (2.5in) diameter at least, and at a slightly lower angle to facilitate drainage.
- 2 Using a 65mm (2.5in) core drill, drill a hole in the wall. Make sure that the hole is drilled at a slight downward angle, so that the outdoor end of the hole is lower than the indoor end by about 5mm to 7mm (0.2-0.275in). This will ensure proper water drainage. (See Fig. 3.2 )
- 3 Place the protective wall cuff in the hole. This protects the edges of the hole and will help seal it when you finish the installation process.



#### NOTE

#### For concrete or brick walls

If the wall is made of brick, concrete, or similar material, drill 5mm-diameter (0.2in-diameter) holes in the wall and insert the sleeve anchors provided. Then secure the mounting plate to the wall by tightening the screws directly into the clip anchors.



#### CAUTION

When drilling the wall hole, make sure to avoid wires, plumbing, and other sensitive components.







Fig. 3.2

## MOUNTING PLATE DIMENSIONS


Different models have different mounting plates. In order to ensure that you have ample room to mount the indoor unit, the diagrams to the right show different types of mounting plates along with the following dimensions:

- Width of mounting plate
- Height of mounting plate
- Width of indoor unit relative to plate
- Height of indoor unit relative to plate
- Recommended position of wall hole (both to the left and right of mounting plate)
- Relative distances between screw holes


### Correct orientation of Mounting Plate




Model B



Model C



Model D



Model E

#### Step 4: Prepare refrigerant piping

The refrigerant piping is inside an insulating sleeve attached to the back of the unit. You must prepare the piping before passing it through the hole in the wall. Refer to the Refrigerant Piping Connection section of this manual for detailed instructions on pipe flaring and flare torque requirements, technique, etc.

- ❶ Based on the position of the wall hole relative to the mounting plate, choose the side from which the piping will exit the unit.
- ❷ If the wall hole is behind the unit, keep the knock-out panel in place. If the wall hole is to the side of the indoor unit, remove the plastic knock-out panel from that side of the unit. (See Fig. 3.3). This will create a slot through which your piping can exit the unit. Use needle nose pliers if the plastic panel is too difficult to remove by hand.




Fig. 3.3




Fig. 3.4

- ❸ Use scissors to cut down the length of the insulating sleeve to reveal about 15cm (6in) of the refrigerant piping. This serves two purposes:
  - To facilitate the Refrigerant Piping Connection process
  - To facilitate Gas Leak Checks and enable you to check for dents
- ❹ If existing connective piping is already embedded in the wall, proceed directly to the Connect Drain Hose step. If there is no embedded piping, connect the indoor unit's refrigerant piping to the connective piping that will join the indoor and outdoor units. Refer to the Refrigerant Piping Connection section of this manual for detailed instructions.
- ❺ Based on the position of the wall hole relative to the mounting plate, determine the necessary angle of your piping.
- ❻ Grip the refrigerant piping at the base of the bend.
- ❼ Slowly, with even pressure, bend the piping towards the hole. Do not dent or damage the piping during the process.




#### NOTE

##### On piping angle

*Refrigerant piping can exit the indoor unit from four different angles:*

- Left-hand side
- Left rear
- Right-hand side
- Right rear

*Refer to Fig. 3.4 for details.*



#### CAUTION

*Be extremely careful not to dent or damage the piping while bending them away from the unit. Any dents in the piping will affect the unit's performance.*

### Step 5: Connect drain hose

By default, the drain hose is attached to the left hand side of unit (when you're facing the back of the unit). However, it can also be attached to the right-hand side.

- 1 To ensure proper drainage, attach the drain hose on the same side that your refrigerant piping exits the unit.
- 2 Attach drain hose extension (purchased separately) to the end of drain hose.
- 3 Wrap the connection point firmly with Teflon tape to ensure a good seal and to prevent leaks.
- 4 For the portion of the drain hose that will remain indoors, wrap it with foam pipe insulation to prevent condensation.
- 5 Remove the air filter and pour a small amount of water into the drain pan to make sure that water flows from the unit smoothly.

### NOTE

#### On drain hose placement

Make sure to arrange the drain hose according to Fig. 3.5.

- ⊘ **DO NOT** kink the drain hose.
- ⊘ **DO NOT** create a water trap.
- ⊘ **DO NOT** put the end of drain hose in water or a container that will collect water.

### PLUG THE UNUSED DRAIN HOLE

To prevent unwanted leaks you must plug the unused drain hole with the rubber plug provided.




Fig. 3.5

**CORRECT**  
Make sure there are no kinks or dent in drain hose to ensure proper drainage.





Fig. 3.6



Fig. 3.7

**NOT CORRECT**  
Do not place the end of the drain hose in water or in containers that collect water. This will prevent proper drainage.




Fig. 3.8



## CAUTIONS

### Before performing electrical work, read these regulations

- 1 All wiring must comply with local and national electrical codes, and must be installed by a licensed electrician.
- 2 All electrical connections must be made according to the Electrical Connection Diagram located on the panels of the indoor and outdoor units.
- 3 If there is a serious safety issue with the power supply, stop work immediately. Explain your reasoning to the client, and refuse to install the unit until the safety issue is properly resolved.
- 4 Power voltage should be within 90-100% of rated voltage. Insufficient power supply can cause malfunction, electrical shock, or fire.
- 5 If connecting power to fixed wiring, install a surge protector and main power switch with a capacity of 1.5 times the maximum current of the unit.
- 6 If connecting power to fixed wiring, a switch or circuit breaker that disconnects all poles and has a contact separation of at least 1/8in (3mm) must be incorporated in the fixed wiring. The qualified technician must use an approved circuit breaker or.
- 7 Only connect the unit to an individual branch circuit outlet. Do not connect another appliance to that outlet.
- 8 Make sure to properly ground the air conditioner.
- 9 Every wire must be firmly connected. Loose wiring can cause the terminal to overheat, resulting in product malfunction and possible fire.
- 10 Do not let wires touch or rest against refrigerant tubing, the compressor, or any moving parts within the unit.
- 11 If the unit has an auxiliary electric heater, it must be installed at least 1 meter (40in) away from any combustible materials.



## WARNING

BEFORE PERFORMING ANY ELECTRICAL OR WIRING WORK, TURN OFF THE MAIN POWER TO THE SYSTEM.

### Step 6: Connect signal cable

The signal cable enables communication between the indoor and outdoor units. You must first choose the right cable size before preparing it for connection.

#### Cable Types

- Indoor Power Cable (if applicable): H05VV-F or H05V2V2-F
- Outdoor Power Cable: H07RN-F
- Signal Cable: H07RN-F

#### Minimum Cross-Sectional Area of Power and Signal Cables

##### North America

Appliance Amps (A)	AWG
10	18
13	16
18	14
25	12
30	10

##### Other Regions

Rated Current of Appliance (A)	Nominal Cross-Sectional Area (mm <sup>2</sup> )
> 3 and ≤ 6	0.75
> 6 and ≤ 10	1
> 10 and ≤ 16	1.5
> 16 and ≤ 25	2.5
> 25 and ≤ 32	4
> 32 and ≤ 40	6

## CHOOSE THE RIGHT CABLE SIZE

The size of the power supply cable, signal cable, fuse, and switch needed is determined by the maximum current of the unit. The maximum current is indicated on the nameplate located on the side panel of the unit. Refer to this nameplate to choose the right cable, fuse, or switch.

## TAKE NOTE OF FUSE SPECIFICATIONS

The air conditioner's circuit board (PCB) is designed with a fuse to provide overcurrent protection. The specifications of the fuse are printed on the circuit board, such as: T3.15A/250VAC, T5A/250VAC, etc.

- 1 Prepare the cable for connection:
  - a Using wire strippers, strip the rubber jacket from both ends of signal cable to reveal about 15cm (6in) of the wires inside.
  - b Strip the insulation from the ends of the wires.
  - c Using wire crimper, crimp u-type lugs on the ends of the wires.

## PAY ATTENTION TO LIVE WIRE

While crimping wires, make sure you clearly distinguish the Live ("L") Wire from other wires.

- 2 Open front panel of the indoor unit.
- 3 Using a screwdriver, open the wire box cover on the right side of the unit. This will reveal the terminal block.




Fig. 3.9

The Wiring Diagram is located on the inside of the indoor unit's wire cover.



## WARNING

*ALL WIRING MUST PERFORMED STRICTLY IN ACCORDANCE WITH THE WIRING DIAGRAM LOCATED ON THE INSIDE OF THE INDOOR UNIT'S WIRE COVER.*

- 4 Unscrew the cable clamp below the terminal block and place it to the side.
- 5 Facing the back of the unit, remove the plastic panel on the bottom left-hand side.
- 6 Feed the signal wire through this slot, from the back of the unit to the front.
- 7 Facing the front of the unit, match the wire colors with the labels on the terminal block, connect the u-lug and and firmly screw each wire to its corresponding terminal.

## CAUTION

### DO NOT MIX UP LIVE AND NULL WIRES

*This is dangerous, and can cause the air conditioning unit to malfunction.*

- After checking to make sure every connection is secure, use the cable clamp to fasten the signal cable to the unit. Screw the cable clamp down tightly.
- Replace the wire cover on the front of the unit, and the plastic panel on the back.

## NOTE

### ABOUT WIRING

*THE WIRING CONNECTION PROCESS MAY DIFFER SLIGHTLY BETWEEN UNITS.*

#### Step 7: Wrap piping and cables

Before passing the piping, drain hose, and the signal cable through the wall hole, you must bundle them together to save space, protect them, and insulate them.

- Bundle the drain hose, refrigerant pipes, and signal cable according to Fig. 3.12 .




Fig. 3.12

## DRAIN HOSE MUST BE ON BOTTOM

Make sure that the drain hose is at the bottom of the bundle. Putting the drain hose at the top of the bundle can cause the drain pan to overflow, which can lead to fire or water damage.

## DO NOT INTERTWINE SIGNAL CABLE WITH OTHER WIRES

While bundling these items together, do not intertwine or cross the signal cable with any other wiring.

- Using adhesive vinyl tape, attach the drain hose to the underside of the refrigerant pipes.
- Using insulation tape, wrap the signal wire, refrigerant pipes, and drain hose tightly together. Double-check that all items are bundled in accordance with Fig. 3.12 .

## DO NOT WRAP ENDS OF PIPING

When wrapping the bundle, keep the ends of the piping unwrapped. You need to access them to test for leaks at the end of the installation process (refer to Electrical Checks and Leak Checks section of this manual).

#### Step 8: Mount indoor unit

If you installed new connective piping to the outdoor unit, do the following:

- If you have already passed the refrigerant piping through the hole in the wall, proceed to Step 4.
- Otherwise, double-check that the ends of the refrigerant pipes are sealed to prevent dirt or foreign materials from entering the pipes.
- Slowly pass the wrapped bundle of refrigerant pipes, drain hose, and signal wire through the hole in the wall.
- Hook the top of the indoor unit on the upper hook of the mounting plate.
- Check that unit is hooked firmly on mounting by applying slight pressure to the left and right-hand sides of the unit. The unit should not jiggle or shift.
- Using even pressure, push down on the bottom half of the unit. Keep pushing down until the unit snaps onto the hooks along the bottom of the mounting plate.
- Again, check that the unit is firmly mounted by applying slight pressure to the left and the right-hand sides of the unit.



**If refrigerant piping is already embedded in the wall, do the following:**

- ❶ Hook the top of the indoor unit on the upper hook of the mounting plate.
- ❷ Use a bracket or wedge to prop up the unit, giving you enough room to connect the refrigerant piping, signal cable, and drain hose. Refer to Fig. 3.13 for an example.
- ❸ Connect drain hose and refrigerant piping (refer to Refrigerant Piping Connection section of this manual for instructions).
- ❹ Keep pipe connection point exposed to perform the leak test (refer to Electrical Checks and Leak Checks section of this manual).
- ❺ After the leak test, wrap the connection point with insulation tape.
- ❻ Remove the bracket or wedge that is propping up the unit.
- ❼ Using even pressure, push down on the bottom half of the unit. Keep pushing down until the unit snaps onto the hooks along the bottom of the mounting plate.





Fig. 3.13

## UNIT IS ADJUSTABLE


Keep in mind that the hooks on the mounting plate are smaller than the holes on the back of the unit. If you find that you don't have ample room to connect embedded pipes to the indoor unit, the unit can be adjusted left or right by about 30-50mm (1.25-1.95in), depending on the model. (See Fig. 3.14).



Move to left or right

Fig. 3.14

## OUTDOOR UNIT INSTALLATION



## INSTALLATION INSTRUCTIONS – OUTDOOR UNIT

### Step 1: Select installation location

Before installing the outdoor unit, you must choose an appropriate location. The following are standards that will help you choose an appropriate location for the unit.

Proper installation locations meet the following standards:

- ☑ Meets all spatial requirements shown in Installation Space Requirements ( Fig. 4.1 )
- ☑ Good air circulation and ventilation
- ☑ Firm and solid—the location can support the unit and will not vibrate
- ☑ Noise from the unit will not disturb others
- ☑ Protected from prolonged periods of direct sunlight or rain.




Fig. 4.1

**DO NOT** install unit in the following locations:

- ⊘ Near an obstacle that will block air inlets and outlets
- ⊘ Near a public street, crowded areas, or where noise from the unit will disturb others
- ⊘ Near animals or plants that will be harmed by hot air discharge
- ⊘ Near any source of combustible gas
- ⊘ In a location that is exposed to large amounts of dust
- ⊘ In a location exposed to a excessive amounts of salty air

If the unit is exposed to heavy wind:  
Install unit so that air outlet fan is at a 90° angle to the direction of the wind. If needed, build a barrier in front of the unit to protect it from extremely heavy winds.  
See Fig. 4.2 and Fig. 4.3 below.




Fig. 4.2




Fig. 4.3

If the unit is frequently exposed to heavy rain or snow:  
Build a shelter above the unit to protect it from the rain or snow. Be careful not to obstruct air flow around the unit.

If the unit is frequently exposed to salty air (seaside):  
Use outdoor unit that is specially designed to resist corrosion.

### Step 2: Install drain joint

Heat pump units require a drain joint. Before bolting the outdoor unit in place, you must install the drain joint at the bottom of the unit. Note that there are two different types of drain joints depending on the type of outdoor unit.

If the drain joint comes with a rubber seal (see Fig. 4.4 - A), do the following:

- ❶ Fit the rubber seal on the end of the drain joint that will connect to the outdoor unit.
- ❷ Insert the drain joint into the hole in the base pan of the unit.
- ❸ Rotate the drain joint 90° until it clicks in place facing the front of the unit.
- ❹ Connect a drain hose extension (not included) to the drain joint to redirect water from the unit during heating mode.

If the drain joint doesn't come with a rubber seal (see Fig. 4.4 - B), do the following:

- ❶ Insert the drain joint into the hole in the base pan of the unit. The drain joint will click in place.
- ❷ Connect a drain hose extension (not included) to the drain joint to redirect water from the unit during heating mode.




Fig. 4.4

### CAUTION

#### In cold climates

Make sure that the drain hose is as vertical as possible to ensure swift water drainage. If water drains too slowly, it can freeze in the hose and flood the unit.

### Step 3: Anchor outdoor unit

The outdoor unit can be anchored to the ground or to a wall-mounted bracket.

## UNIT MOUNTING DIMENSIONS

The following is a list of different outdoor unit sizes and the distance between their mounting feet.  
Prepare the installation base of the unit according to the dimensions below.




Fig. 4.5

Outdoor Unit Dimensions (mm) W x H x D	Mounting Dimensions	
	Distance A (mm)	Distance B (mm)
685x430x260 (27"x17"x10.25")	460 (18.10")	276 (10.85")
700x540x240 (27.5"x21.25"x9.45")	458 (18")	250 (9.85")
780x540x250 (30.7"x21.25"x9.85")	549 (21.6")	276 (10.85")
760x590x285 (29.9"x23.2"x11.2")	530 (20.85")	290 (11.4")
845x700x320 (33.25"x27.5"x12.6")	560 (22")	335 (13.2")
810x558x310 (31.9"x22"x12.2")	549 (21.6")	325 (12.8")
709x550x270 (27.9"x21.65"x10.63")	450 (17.7")	260 (10.24")
770x555x300 (30.3"x21.85"x11.81")	487 (19.2")	298 (11.73")
800x554x333 (31.5"x21.8"x13.1")	514 (20.24")	340 (13.39")
845x700x340 (33.25"x27.5"x13.38")	540 (21.26")	350 (13.8")
900x860x315 (35.4"x33.85"x12.4")	590 (23.2")	333 (13.1")
945x810x395 (37.2"x31.9"x15.55")	640 (25.2")	405 (15.95")
946x810x420 (37.21"x31.9"x16.53")	673 (26.5")	403 (15.87")

**If you will install the unit on the ground or on a concrete mounting platform, do the following:**

- 1 Mark the positions for four expansion bolts based on dimensions in the Unit Mounting Dimensions chart.
- 2 Pre-drill holes for expansion bolts.
- 3 Clean concrete dust away from holes.
- 4 Place a nut on the end of each expansion bolt.
- 5 Hammer expansion bolts into the pre-drilled holes.
- 6 Remove the nuts from expansion bolts, and place outdoor unit on bolts.
- 7 Put washer on each expansion bolt, then replace the nuts.
- 8 Using a wrench, tighten each nut until snug.



### WARNING

*WHEN DRILLING INTO CONCRETE, EYE PROTECTION IS RECOMMENDED AT ALL TIMES.*

If you will install the unit on a wall-mounted bracket, do the following:

## CAUTION

*Before installing a wall-mounted unit, make sure that the wall is made of solid brick, concrete, or of similarly strong material. The wall must be able to support at least four times the weight of the unit.*

- 1 Mark the position of bracket holes based on dimensions in the Unit Mounting Dimensions chart.
- 2 Pre-drill the holes for the expansion bolts.
- 3 Clean dust and debris away from holes.
- 4 Place a washer and nut on the end of each expansion bolt.
- 5 Thread expansion bolts through holes in mounting brackets, put mounting brackets in position, and hammer expansion bolts into the wall.
- 6 Check that the mounting brackets are level.
- 7 Carefully lift unit and place its mounting feet on brackets.
- 8 Bolt the unit firmly to the brackets.

## TO REDUCE VIBRATIONS OF WALL- MOUNTED UNIT

If allowed, you can install the wall-mounted unit with rubber gaskets to reduce vibrations and noise.


### Step 4: Connect signal and power cables

The outside unit's terminal block is protected by an electrical wiring cover on the side of the unit.

A comprehensive wiring diagram is printed on the inside of the wiring cover.

## CONNECT THE CABLE TO THE OUTDOOR UNIT

- 1 Remove the electrical control board cover from the outdoor unit by loosening the screw.
- 2 Connect the connective cables to the terminals as identified with their respective matched numbers on the terminal block of indoor and outdoor units.
- 3 Secure the cable onto the control board with the cord clamp.
- 4 To prevent the ingress of water, form a loop of the connective cable as illustrated in the installation diagram of indoor and outdoor units.
- 5 Insulate unused cords (conductors) with PVC-tape. Process them so they do not touch any electrical or metal parts.





## WARNING

*BEFORE PERFORMING ANY ELECTRICAL OR WIRING WORK, TURN OFF THE MAIN POWER TO THE SYSTEM.*

Prepare the cable for connection:

### USE THE RIGHT CABLE

- Indoor Power Cable (if applicable): H05VV-F or H05V2V2-F
- Outdoor Power Cable: H07RN-F
- Signal Cable: H07RN-F

#### Minimum Cross-Sectional Area of Power and Signal Cables

##### North America

Appliance Amps (A)	AWG
10	18
13	16
18	14
25	12
30	10

##### Other Regions

Rated Current of Appliance (A)	Nominal Cross-Sectional Area (mm <sup>2</sup> )
> 3 and ≤ 6	0.75
> 6 and ≤ 10	1
> 10 and ≤ 16	1.5
> 16 and ≤ 25	2.5
> 25 and ≤ 32	4
> 32 and ≤ 40	6

Using wire strippers, strip the rubber jacket from both ends of cable to reveal about 15cm (6in) of the wires inside.

Strip the insulation from the ends of the wires.

Using a wire crimper, crimp u-lugs on the ends of the wires.

## PAY ATTENTION TO LIVE WIRE

While crimping wires, make sure you clearly distinguish the Live ("L") Wire from other wires.



## WARNING

*ALL WIRING MUST PERFORMED STRICTLY IN ACCORDANCE WITH THE WIRING DIAGRAM LOCATED INSIDE THE OUTDOOR UNIT S WIRE COVER.*

- 2 Unscrew the electrical wiring cover and remove it.
- 3 Unscrew the cable clamp below the terminal block and place it to the side.
- 4 Match the wire colors/labels with the labels on the terminal block, and firmly screw the u-lug of each wire to its corresponding terminal.
- 5 After checking to make sure every connection is secure, loop the wires around to prevent rain water from flowing into the terminal.
- 6 Using the cable clamp, fasten the cable to the unit. Screw the cable clamp down tightly.
- 7 Insulate unused wires with PVC electrical tape. Arrange them so that they do not touch any electrical or metal parts.
- 8 Replace the wire cover on the side of the unit, and screw it in place.





Fig. 4.6



### NOTE ON PIPE LENGTH

The length of refrigerant piping will affect the performance and energy efficiency of the unit. Nominal efficiency is tested on units with a pipe length of 5 meters (16.5ft).

Refer to the table below for specifications on the maximum length and drop height of piping.

Maximum Length and Drop Height of Refrigerant Piping per Unit Model

Model	Capacity (BTU/h)	Max. Length (m)	Max. Drop Height (m)
R410A Inverter Split Air Conditioner	< 15,000	25 (82ft)	10 (33ft)
	≥ 15,000 and < 24,000	30 (98.5ft)	20 (66ft)
	≥ 24,000 and < 36,000	50 (164ft)	25 (82ft)
	≥ 36,000 and ≥ 60,000	65 (213ft)	30 (98.5ft)

### CONNECTION INSTRUCTIONS – REFRIGERANT PIPING

#### Step 1: Cut pipes

When preparing refrigerant pipes, take extra care to cut and flare them properly. This will ensure efficient operation and minimize the need for future maintenance.

- 1 Measure the distance between the indoor and outdoor units.

- 2 Using a pipe cutter, cut the pipe a little longer than the measured distance.
- 3 Make sure that the pipe is cut at a perfect 90° angle. Refer to Fig. 5.1 for bad cut examples.




Fig. 5.1



## CAUTION

### Do not deform pipe while cutting

Be extra careful not to damage, dent, or deform the pipe while cutting. This will drastically reduce the heating efficiency of the unit.

### Step 2: Remove burrs

Burrs can affect the air-tight seal of refrigerant piping connection. They must be completely removed.

- 1 Hold the pipe at a downward angle to prevent burrs from falling into the pipe.
- 2 Using a reamer or de burring tool, remove all burrs from the cut section of the pipe.




Fig. 5.2

### Step 3: Flare pipe ends

Proper flaring is essential to achieve an airtight seal.

- 1 After removing burrs from cut pipe, seal the ends with PVC tape to prevent foreign materials from entering the pipe.
- 2 Sheath the pipe with insulating material.
- 3 Place flare nuts on both ends of pipe. Make sure they are facing in the right direction, because you can't put them on or change their direction after flaring. See Fig. 5.3 .




Fig. 5.3

- 4 Remove PVC tape from ends of pipe when ready to perform flaring work.
- 5 Clamp flare form on the end of the pipe. The end of the pipe must extend beyond the edge of the flare form in accordance with the dimensions shown in the table below.




Fig. 5.4

### PIPING EXTENSION BEYOND FLARE FORM

Outer Diameter of Pipe (mm)	A (mm)	
	Min.	Max.
Ø 6.35 (Ø 0.25")	0.7 (0.0275")	1.3 (0.05")
Ø 9.52 (Ø 0.375")	1.0 (0.04")	1.6 (0.063")
Ø 12.7 (Ø 0.5")	1.0 (0.04")	1.8 (0.07")
Ø 16 (Ø 0.63")	2.0 (0.078")	2.2 (0.086")




Fig. 5.5

- 6 Place flaring tool onto the form.
- 7 Turn the handle of the flaring tool clockwise until the pipe is fully flared.
- 8 Remove the flaring tool and flare form, then inspect the end of the pipe for cracks and even flaring.

#### Step 4: Connect pipes

When connecting refrigerant pipes, be careful not to use excessive torque or to deform the piping in any way. You should first connect the low-pressure pipe, then the high-pressure pipe.

#### MINIMUM BEND RADIUS

When bending connective refrigerant piping, the minimum bending radius is 10cm. See Fig 5.6




Fig. 5.6

#### INSTRUCTIONS FOR CONNECTING PIPING TO INDOOR UNIT

- 1 Align the center of the two pipes that you will connect. See Fig. 5.7.




Fig. 5.7

- 2 Tighten the flare nut as tightly as possible by hand.
- 3 Using a spanner, grip the nut on the unit tubing.
- 4 While firmly gripping the nut on the unit tubing, use a torque wrench to tighten the flare nut according to the torque values in the Torque Requirements table below. Loosen the flaring nut slightly, then tighten again.




Fig. 5.8

#### TORQUE REQUIREMENTS

Outer Diameter of Pipe (mm)	Tightening Torque (N·cm)	Add. Tightening Torque (N·m)
Ø 6.35 (Ø 0.25")	1,500 (11lb · ft)	1,600 (11.8lb · ft)
Ø 9.52 (Ø 0.375")	2,500 (18.4lb · ft)	2,600 (19.18lb · ft)
Ø 12.7 (Ø 0.5")	3,500 (25.8lb·ft)	3,600 (26.55lb·ft)
Ø 16 (Ø 0.63")	4,500 (33.19lb·ft)	4,700 (34.67lb·ft)

#### CAUTION

##### Do not use excessive torque

Excessive force can break the nut or damage the refrigerant piping. You must not exceed torque requirements shown in the table above.



- 1 Unscrew the cover from the packed valve on the side of the outdoor unit. (See Fig. 5.9)
- 2 Remove protective caps from ends of valves.
- 3 Align flared pipe end with each valve, and tighten the flare nut as tightly as possible by hand.
- 4 Using a spanner, grip the body of the valve. Do not grip the nut that seals the service valve. (See Fig. 5.10)




Fig. 5.9

# **CAUTION**

## **Use spanner to grip main body of valve**

*Torque from tightening the flare nut can snap off other parts of valve.*





Fig. 5.10

- 5 While firmly gripping the body of the valve, use a torque wrench to tighten the flare nut according to the correct torque values.
- 6 Loosen the flaring nut slightly, then tighten again.
- 7 Repeat Steps 3 to 6 for the remaining pipe.



## PREPARATIONS AND PRECAUTIONS

Air and foreign matter in the refrigerant circuit can cause abnormal rises in pressure, which can damage the air conditioner, reduce its efficiency, and cause injury. Use a vacuum pump and manifold gauge to evacuate the refrigerant circuit, removing any non-condensable gas and moisture from the system.

Evacuation should be performed upon initial installation and when unit is relocated.


## BEFORE PERFORMING EVACUATION

✓ Check to make sure that both high pressure and low-pressure pipes between the indoor and outdoor units are connected properly in accordance with the Refrigerant Piping Connection section of this manual.

✓ Check to make sure all wiring is connected properly.

## EVACUATION INSTRUCTIONS

- 1 Before using the manifold gauge and vacuum pump, read their operation manuals to familiarize yourself with how to use them properly.
- 2 Connect the charge hose of the manifold gauge to service port on the outdoor unit's low pressure valve.
- 3 Connect another charge hose from the manifold gauge to the vacuum pump.



- 3 Open the Low Pressure side of the manifold gauge. Keep the High Pressure side closed.
- 4 Turn on the vacuum pump to evacuate the system.
- 5 Run the vacuum for at least 15 minutes, or until the Compound Meter reads -76cmHG (-10 Pa).
- 6 Close the Low Pressure side of the manifold gauge, and turn off the vacuum pump.
- 7 Wait for 5 minutes, then check that there has been no change in system pressure.
- 8 If there is a change in system pressure, refer to Gas Leak Check section for information on how to check for leaks. If there is no change in system pressure, unscrew the cap from the packed valve (high pressure valve).
- 9 Insert hexagonal wrench into the packed valve (high pressure valve) and open the valve by turning the wrench in a 1/4 counterclockwise turn. Listen for gas to exit the system, then close the valve after 5 seconds.
- 10 Watch the Pressure Gauge for one minute to make sure that there is no change in pressure. The Pressure Gauge should read slightly higher than atmospheric pressure.




Fig. 6.2

- 11 Remove the charge hose from the service port.
- 12 Using hexagonal wrench, fully open both the high pressure and low pressure valves.
- 13 Tighten valve caps on all three valves (service port, high pressure, low pressure) by hand. You may tighten it further using a torque wrench if needed.

### CAUTION

#### Open valve stems gently

When opening valve stems, turn the hexagonal wrench until it hits against the stopper. Do not try to force the valve to open further.



### NOTE

#### On adding refrigerant

Some systems require additional charging depending on pipe lengths. The standard pipe length varies according to local regulations. For example, in North America, the standard pipe length is 7.5m (25ft).

In other areas, the standard pipe length is 5m (16ft). The additional refrigerant to be charged can be calculated using the following formula:


#### ADDITIONAL REFRIGERANT PER PIPE LENGTH

Connective Pipe Length (m)	Air Purging Method	Additional Refrigerant	
≤ Standard pipe length	Vacuum Pump	N/A	
> Standard pipe length	Vacuum Pump	Liquid Side: Ø 6.35 (ø 0.25") R22: (Pipe length – standard length) x 30g/m (Pipe length – standard length) x 0.32oz/ft	Liquid Side: Ø 9.52 (ø 0.375") R22: (Pipe length – standard length) x 60g/m (Pipe length – standard length) x 0.64oz/ft
		Inverter R410A: (Pipe length – standard length) x 15g/m (Pipe length – standard length) x 0.16oz/ft	Inverter R410A: (Pipe length – standard length) x 30g/m (Pipe length – standard length) x 0.32oz/ft
		Fixed-frequency R410A: (Pipe length – standard length) x 20g/m (Pipe length – standard length) x 0.21oz/ft	Fixed-frequency R410A: (Pipe length – standard length) x 40g/m (Pipe length – standard length) x 0.42oz/ft



### CAUTION

DO NOT mix refrigerant types.



## ELECTRICAL SAFETY CHECKS

After installation, confirm that all electrical wiring is installed in accordance with local and national regulations, and according to the Installation Manual.

### BEFORE TEST RUN

- Check Grounding Work
- Measure grounding resistance by visual detection and with grounding resistance tester. Grounding resistance must be less than 4.



### NOTE

*This may not be required for some locations in the US.*

### DURING TEST RUN

- Check for Electrical Leakage
- During the Test Run, use an electro probe and multimeter to perform a comprehensive electrical leakage test.
- If electrical leakage is detected, turn off the unit immediately and call a licensed electrician to find and resolve the cause of the leakage.



### WARNING

#### RISK OF ELECTRIC SHOCK

ALL WIRING MUST COMPLY WITH LOCAL AND NATIONAL ELECTRICAL CODES, AND MUST BE INSTALLED BY A LICENSED ELECTRICIAN.

## GAS LEAK CHECKS

There are two different methods to check for gas leaks.

### Soap and Water Method

Using a soft brush, apply soapy water or liquid detergent to all pipe connection points on the indoor unit and outdoor unit. The presence of bubbles indicates a leak.

### Leak Detector Method

If using leak detector, refer to the device's operation manual for proper usage instructions.

## AFTER PERFORMING GAS LEAK CHECKS

After confirming that the all pipe connection points DO NOT leak, replace the valve cover on the outside unit.

## TEST RUN

### BEFORE TEST RUN

Only perform test run after you have completed the following steps:

- Electrical Safety Checks – Confirm that the unit's electrical system is safe and operating properly
- Gas Leak Checks – Check all flare nut connections and confirm that the system is not leaking
- Confirm that gas and liquid (high and low pressure) valves are fully open.

### TEST RUN INSTRUCTIONS

You should perform the Test Run for at least 30 minutes.

- 1 Connect power to the unit.
- 2 Press the ON/OFF button on the remote control to turn it on.
- 3 Press the MODE button to scroll through the following functions, one at a time:
  - COOL – Select lowest possible temperature
  - HEAT – Select highest possible temperature
- 4 Let each function run for 5 minutes, and perform the following checks:

List of Checks to Perform	PASS/FAIL	
No electrical leakage		
Unit is properly grounded		
All electrical terminals properly covered		
Indoor and outdoor units are solidly installed		
All pipe connection points do not leak	Outdoor (2):	Indoor (2):
Water drains properly from drain hose		
All piping is properly insulated		
Unit performs COOL function properly		
Unit performs HEAT function properly		
Indoor unit louvers rotate properly		
Indoor unit responds to remote controller		

## DOUBLE-CHECK PIPE CONNECTIONS


During operation, the pressure of the refrigerant circuit will increase. This may reveal leaks that were not present during your initial leak check. Take time during the Test Run to double-check that all refrigerant pipe connection points do not have leaks. Refer to Gas Leak Check section for instructions.

- 5 After the Test Run is successfully complete, and you confirm that all checks points in List of Checks to Perform have PASSED, do the following:
  - a Using remote control, return unit to normal operating temperature.
  - b Using insulation tape, wrap the indoor refrigerant pipe connections that you left uncovered during the indoor unit installation process.

## IF AMBIENT TEMPERATURE IS BELOW 17°C (63°F)

You can't use the remote control to turn on the COOL function when the ambient temperature is below 17°C. In this instance, you can use the MANUAL CONTROL button to test the COOL function.

- 1 Lift the front panel of the indoor unit, and raise it until it clicks in place.
- 2 The MANUAL CONTROL button is located on the right-hand side of the unit. Press it 2 times to select the COOL function. See Fig 8.1 .
- 3 Perform Test Run as normal.



This appliance contains refrigerant and other potentially hazardous materials. When disposing of this appliance, the law requires special collection and treatment. Do not dispose of this product as household waste or unsorted municipal waste.

When disposing of this appliance, you have the following options:

- Dispose of the appliance at designated municipal electronic waste collection facility.
- When buying a new appliance, the retailer will take back the old appliance free of charge.
- The manufacturer will take back the old appliance free of charge.
- Sell the appliance to certified scrap metal dealers.

### Special notice

Disposing of this appliance in the forest or other natural surroundings endangers your health and is bad for the environment. Hazardous substances may leak into the ground water and enter the food chain.

The design and specifications are subject to change without prior notice for product improvement. Consult with the sales agency or manufacturer for details.



